


# Kitchen Scale


## User's Manual



Before use, please read these instructions carefully




### EB Product Structure

The machine



Display Symbols Description




| Symbol  | Description                    | Explain                                    |
|---|--------------------------------|--|
| <b>ml</b>   | Volume units                   | ml 1ml=1cm <sup>3</sup>                    |
| <b>g</b>  | Weight Unit                    | gram 1000g=1kg                             |
| <b>fl.oz</b>  | Volume units<br>(Fluid ounces) | 1 fl.oz(AM)=29.57ml<br>1 fl.oz(EN)=28.41ml |
| <b>Lb : OZ</b>  | Weight Unit                    | lb: oz (1000g=2Lb:3.3oz)                   |
|  | Minus sign                     | When said negative                         |
|  | Low battery symbol             | Said the lack of electricity               |
|  | Countdown function             | [This product is no function]              |

## EB Use

For the first time, follow the arrows indicate the battery cover to remove the battery cover, battery direction in accordance with the instructions inside the battery compartment, put on the battery cover.

### Insert the battery



- 1.As shown, open the battery cover.
- 2.Based on Battery slot's "+" "-" polarity indication.
- 3.Put on the battery cover.

### Select units



LCD Full Screen



- 4.Press starting up.
- 5.Select units  
For the first time or to replace the battery, you can choose different unit [g、Lb:oz、ml OR fl.oz].

### Ordinary weighing



- 6.When starting up screen shows "0", press button to select the unit.



- 7.When the display shows "0",gently put the food on the scale surface.
- 8.The display shows the weight value items.

### Tare weighing function



- 9.When the display shows "0",gently put the Container on the scale surface.



- 10.After the display shows the weight of the container, press , the weight of the container is cleared. Screen shows "0."



- 11.Put food into the container, the display shows the weight of food.



- 12.Product automatically shut down after idle 120 seconds or press three seconds to shutdown.

## EB Product Specifications

|  |  |                 |                 |
|--|--|-----------------|-----------------|
| Name                                   | Kitchen scale C305   |                 |                 |
| Parameters                             | 212*155*30mm   |                 |                 |
| NW                                     | 355g (include 3 batteries)                                       |                 |                 |
| Power supply                           | 3*AAA batteries  |                 |                 |
| Unit                                   | g/Lb:oz/ml/fl.oz   |                 |                 |
| Maximum capacity                       | 10000g   | 5000g           | 3000g           |
| Minimum capacity                       | 3g   | 0.5g            | 0.5g            |
| scale division                         | 1g   | 0.1g            | 0.1g            |
| Graduation<br>(Temperature 25±5°C)     | 3~5000g ±3g  | 0.5~ 500g ±0.5g | 0.5~ 500g ±0.5g |
|  | 500~2000g ±1g  | 500~2000g ±1g   | 500~2000g ±1g   |
|  | 5000~10000g ±8g  | 2000~5000g ±3g  | 2000~3000g ±3g  |
| Work environment                       | Temperature: 0~40°C Humidity: ≤90%RH<br>Pressure: 80kPa~106kPa   |                 |                 |
| Storage and transportation environment | Temperature: -20~60°C Humidity: ≤90%RH<br>Pressure: 50kPa~106kPa |                 |                 |

Performance improvements above specifications subject to change without notice.

Note: 1.Factory default unit is g; after replacing the battery, the unit is automatically set to the default value of g.  
2.After tare Weighing,if you take away food and containers, the display will show "-" and the weight of the container.Said negative weight.